




# Dell Optiplex GX620 CMOS Battery Replacement

This guide will teach you how to remove the CMOS battery.

Written By: Kristina



## INTRODUCTION

The CMOS battery maintains the time, date, hard disk and other configuration settings in the CMOS memory. When your CMOS battery dies, your system settings will be lost.

---



### TOOLS:


- [Phillips #0 Screwdriver](#) (1)
  - [Spudger](#) (1)
-

## Step 1 — Dell Optiplex GX620 Side Panel Disassembly



- With the computer standing upright, firmly pull on the tab at the back of the computer.
- When the side panel pops free, gently pull the panel away from the computer.
- ⓘ If you have trouble freeing the side panel from the case, you may need to pull the tab a bit harder.

## Step 2 — Removing the CMOS Battery



- Insert a tool beside the battery and gently pry the battery out.
- ⚠ Using a screwdriver to pry open anything can harm your device. Instead, use a spudger or a plastic opening tool.

To reassemble your device, follow these instructions in reverse order. Make sure you place the battery with the flat (positive) side facing up.

